

Installation of PROMAT alley matting

Two installation options:

Option 1

- a- Allow the product to reach room temperature before installation (70°F or 20°C).
- b- Unroll the matting in designated area and determine where you want to fasten the mat to the ground. Pre-drill holes in cement, recommended to place concrete pin every 8" – 10". Pin the product to the ground using 2 1/2" concrete pins and 1" washers.
- c- Stretch the material up to 3% of the length. Pin the other rows every 12' to 18' the length of the roll, using twice the spacing as used on the leading edge. Continue until the end of the roll.

Following this installation method the product should lay flat for up to 3 years.

Actual results depend on:

- Use
- Moisture
- % of pre-stretch
- Variation in temperature

*****If material begins to lay unevenly, re-pin and re-stretch the matting.*****

Option 2

- a- Unroll the matting in designated area and determine where you want to fasten the mat to the ground. Pre-drill holes in cement, recommended to place concrete pin every 8" – 10". Pin the product to the ground using 2 1/2" concrete pins and 1" washers.
- b- If required, prohibit sideways product movement by using Promat Plastic strips. Having the matting inset into the concrete is ideal. Leave about an inch for every 4 feet of width for sideways movement.
- c- If the designated area is longer than the roll length, simply allow room between the rolls for the matting to stretch. Remove excess material when necessary.

NOTE: If installing over a sand base it is highly recommended to pin down the matting to avoid the sand from bunching up underneath the material making it uneven.

NOTE: Surface may be slippery when wet. Also we recommend washing the matting prior to usage with a standard cleaning solution.